
## CCD-POD INSTALL GUIDE

## **DIMENSIONAL RENDERINGS**



## Install Notes:

CCD-POD

24 1/8"

✓ 2 anchor points are located on each side of the doors interior frame (top, bottom, left and right)

Depth

18"

✓ Due to wide variance of possible building materials, anchors are not included

45 1/4"

- ✓ When inserting your anchors be sure to use a framing square to ensure the door is not pulled out of square
- Additional framing and/or support underneath the rear (hanging portion) of the cabinet is recommended
- These specs are accurate but we always suggest having the product physically on site to ensure full understanding of how this product will coordinate with your build

20 3/8"

CCD-POD

43 3/8"

17 1/2"

